
Soyntec®

NEXOOS™ 700

Mouse pad with a multi-cards reader and USB 2.0 ports

User Manual

Introduction

Soyntec® thanks you for buying the ergonomic mouse pad Nexoos 700 with a multi-cards reader, USB ports and an integrated support paper. We wish you enjoy using it.

Nexoos 700 is the most complete and versatile solution for reading/writing the multiple memory cards available. Appreciate also the advantages of USB 2.0 connection.

We recommend you to read this user manual in order to enjoy the product in a safe way and with the best features.

Main features

- High speed connection USB 2.0. Compatible with USB 1.1/1.0.
- Low power consumption makes it perfect for laptop computers.
- Allows read/write several memory cards simultaneously.
- Features status LED indicator.
- Compatible with Windows VISTA / XP / 2000 / 98SE / ME and MAC OS X.
- Compatible with:

CF I (Compact Flash Type I)	XD-Digital Film	MS (Memory Stick)
CF I Pro	XD H	MS PRO
CF I Pro II	XD M	MS MG (Magic Gate)
CF I Elite Pro	XD Picture Card	MS PRO MG HIGH SPEED
CF I Ultra II	XD-Premium Memory	MS PRO MG Extreme III
CF I Ultra x		MS Duo
CF I Extreme	SD 40X	MS PRO Duo
CF I Extreme III	SD 60X	MS PRO Duo MG Ultra II
CF I 40X HS/WA	SD 80X	MS Pro Duo MG High Speed
CF I 80 WA	SD 133X	MS PRO Magic Gate
CF I 133 WA	SD (Secure Digital Card)	MS Duo Magic Gate
CF II (Compact Flash Type II)	SD Elite Pro	MS PRO Duo Magic Gate
CF II Micro Drive	SD Ultra II	MS Select Function
CF II Magicstor	SD Ultra II Plus	MS ROM
CF Ultimate	SD Extreme	MMC (Multimedia Card)
Shoot&Store CF	SD Extreme III	Shoot&Store MS
CF-Digital Film	SD Ultimate	
CF-Premium Memory		MMCmicro*
	Shoot&Store SD	MMC 4.0
SMC (Smart Media Card)	Gaming SD	MMCmobile*
Rom-SMC		MMCplus 200X
Gaming PRO Duo	Mini-SD	MMCplus
Memory Stick Micro*	Micro-SD*	RS-MMC*
* Requires adaptor bundled with the card.		RS-MMC 4.0*
		DV RS-MMC*

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

Product contents

- Mouse pad with a multi-cards reader
- USB cable
- User manual
- CD with drivers.

Card reader installation

Please note that in order to install the Nexoos 700 card reader you need a free USB connector in your computer.

Follow these steps to install the webcam:

1. If your operating system is Windows 98, install the drivers from the provided CD.

Note: If your operating system is Windows VISTA/XP/ME/2000 or MAC OS X, you don't need to install the drivers, but for Windows VISTA/XP/ME/2000 you can optionally install the drivers for having the drives in My PC with special icons ("MMC/SD", "CompactFlash I/II", "SmartMedia/XD", "MS/MS PRO", etc).

2. Connect the card reader to a free USB connector using the USB cable provided.
3. Reboot the computer if needed to finish the installation.

Trademarks

All company, brand and product names are trademarks or registered trademarks of their respective companies.