

MP3 digital player

No driver needed under Windows 2000/XP/ME

Card-insert memory design (support 16MB,64MB,128MB,256MB,512MB,1024MB SD,MMC card)

USB2.0

Multi-function Jog Dial, easy to operate

Several EQ to choose

A-B repeat

Low power dissipation

Cover introduction

1. Power on/playback/pause/stop
2. A-B repeat
3. EQ/Previous/Next/Increase volume/Decrease volume
4. Lock
5. SD,MMC card slot (support 16MB,64MB,128MB,256MB,512MB,1024MB SD,MMC card)
6. Earphone jack



MP3 playback:

1. Power on: press and hold the play button to power on.
2. Playback: the unit will playback automatically after powering on
3. Pause: short press Play button to pause while playing back
4. Stop: press and hold Play button to stop while playing back.
5. Power off: the unit will power off automatically 30 seconds after the music stopped
6. Previous/next: dial the Jog Dial to right, the unit will turn to the next file; dial the Jog Dial to left, it will turn to the previous file.
7. Volume adjustment: dial the Jog Dial to right to increase the volume, and the icon on the LCD will show the increase accordingly; dial the Jog Dial to left to decrease the volume, and the LCD will displays the icon accordingly.
8. EQ adjustment: press the Jog Dial while playing to shift to BASS, JAZZ, ROCK and CLASSIC.