
Soyntec[®]

NEXOOS[™] 500

25-in-1 Card reader USB 2.0

User's Manual

Introduction

Soyntec thanks you for purchasing your new Nexoos 500 card reader. We wish you enjoy using it.

Nexoos 500 is the most complete and versatile solution for reading/writing the multiple memory cards available.

We suggest reading this user manual for enjoying this product is a safe way and with the best performance.

Main features

- High-speed USB 2.0 connection. Compatible with USB 1.1/1.0.
- Low power consumption makes it perfect for laptop computers.
- Allows read/write several memory cards simultaneously.
- Features status LED indicator.
- Compatible with Windows XP / 2000 / 98SE / ME and MAC OS X.
- Compatible with:
 1. CF Type I
 2. CF Type II

Specifications are subject to change without notice.
© 2005 by Soyntec. All rights reserved.

-
3. USB-Enabled CF
 4. CF-Ultra II
 5. MicroDrive
 6. Smart Media Card (SMC)
 7. Secure Digital Card (SD)
 8. Mini-SD
 9. Memory Stick (MS)
 10. MS Magic Gate
 11. MS Pro
 12. MS Duo
 13. MS Pro Duo
 14. MS Select Function
 15. MS RAM Card
 16. Multimedia Card (MMC)
 17. MMC-II
 18. ROM-MMC
 19. RS-MMC
 20. ROM-RS-MMC
 21. MMCplus
 22. MMCmobile
 23. XD Picture Card
 24. Trans Flash (T-Flash) *
 25. C-Flash *

* Requires adaptor bundled with the card.

Product contents

- Card reader.
- CD with drivers.
- USB cable.
- User manual.

Specifications are subject to change without notice.
© 2005 by Soyntec. All rights reserved.

Card reader installation

Please note that in order to install the Nexoos 500 card reader you need a free USB connector in your computer.

Follow these steps to install the webcam:

1. If your operating system is Windows 98, install the drivers from the provided CD.

Note: If your operating system is Windows XP/ME/2000 or MAC OS X, you don't need to install the drivers, but for Windows XP/ME/2000 you can optionally install the drivers for having the drives in My PC with special icons ("MMC/SD", "CompactFlash I/II", "SmartMedia/XD", "MS/MS PRO", etc).

2. Connect the card reader to a free USB connector using the USB cable provided.
3. Reboot the computer if needed to finish the installation.

Trademarks

All company, brand and product names are trademarks or registered trademarks of their respective companies.