

Introduction

Soyntec thanks you for purchasing your new Joinsee 400. We wish you enjoy using it.

Joinsee 400 is a SXGA webcam which provides an easy way to enjoy videoconference using a USB connection to your computer.

We suggest reading this user manual for enjoying this product is a safe way and with the best performance.

Main features

- Innovative design suitable for both laptop and desktop computers.
- Adjustable focus.
- Automatic exposure and gain control.
- Still image resolution: SXGA 1280x1024.
- Video resolution: SXGA 1280x1024.
- Capture speed: Up to 30 fps (VGA) and up to 15 fps (SXGA).
- Includes special button for taking photos.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

- Features status LED indicator.
- USB 2.0/1.1/1.0 connection.
- Compatible with Windows VISTA / XP / 2000

Product contents

- Webcam.
- Headset
- CD with drivers and software.
- User manual.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

Product overview

The following picture shows the main parts of the webcam:



Figura A: Webcam main parts

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

Webcam installation

Please note that in order to install the Joinsee 400 webcam you need a free USB connector in your computer.

Follow these steps to install the webcam:

1. Insert the provided drivers CD and select “Install Joinsee 400 Driver”.
2. Click the “Next” button.
3. Select the type of installation (“Complete” is recommended). Click “Next”.
4. Click “Install” to start copying the files to the computer.
5. Click “Finish” to close the installation wizard.
6. Connect the Joinsee 400 webcam to a free USB connector. The operating system will detect the webcam and it will be ready to use.
7. Press the snapshot button on top of the webcam to launch the monitoring software and check that the Joinsee 400 has been properly installed.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

ArcSoft VideoImpression software installation

1. Insert the provided drivers CD and select “ArcSoft VideoImpression” then click over it”.
2. Select the installation language.
3. Click the “Next” button.
4. The license contract will appear. Click “Yes”.
5. The installation folder can be modified. It is recommended to leave the default folder. Click the “Next” button.
6. The new program group can also be modified. Just leave the default program group and click “Next”. The copy of files will start.
7. Click “Finish” to close the installation wizard.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

ArcSoft WebCam Companion 2 software installation

1. Insert the provided drivers CD and select “ArcSoft WebCam Companion 2” then click over it”.
2. Select the installation language.
3. Click the “Next” button.
4. The license contract will appear. Click “Yes”.
5. The installation folder can be modified. It is recommended to leave the default folder. Click the “Next” button.
6. The new program group can also be modified. Just leave the default program group and click “Next”. The copy of files will start.
7. Click “Finish” to close the installation wizard.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.

Operation of the Guarantee

- 1) Entering <http://support.energysistem.com> and after selecting your product you will be able to find FAQ's (answers to the frequently asked questions) manual, guides of user, drivers and updates.
- 2) If you do not obtain the solution in the support section please contacting us on: support@energysistem.co.uk
- 3) Optionally can be directed to the place where it has bought the product, presenting its invoice or ticket of purchase.

Trademarks

All company, brand and product names are trademarks or registered trademarks of their respective companies.

Specifications are subject to change without notice.

© 2007 by Soyntec. All rights reserved.